



Resetting Your Combination Lock

All Briggs & Riley Torq Spinners come preset with the lock combination **0-0-0** on the Control Panel™. To reset your combination:



1. Unlock the zippers by pushing the slide release button, located next to the zipper pulls on the Control Panel™.



2. Next, you will need to access the lock access pocket (*it's inside the bag, directly underneath the Control Panel™.*) To get there, zip open the bag, lay it open on a flat surface, and then unzip the u-zip lid pocket.



3. Unzip the lock access pocket. Inside, there is a small, square, orange tab. Using your fingers or a pen, pry this plastic tab off and discard it.



4. Once the tab is removed, you'll see the L-track toggle. It looks like a small metal lever. Push this toggle along the L-track: first over, then up. The toggle will lock into the new position.

5. Return to the Control Panel™ on the outside of the bag, and set your new 3-digit combination.



6. Go back to the lock access pocket and push the toggle back down. It will easily pop back into place.

You have now finished resetting your lock. Now you can open the main and front compartments with your new personalized combination.