





**marantz®**

**Network Receiver M-CR510**

Quick Setup Guide

**Start Here**  
**Commencez ici**  
**Iniciar aquí**



# Before you begin


## What's In The Box



M-CR510



Power cord



Remote and batteries




Product manual on CD-ROM

## Required For Setup



Network router




Speakers



Speaker cables

## Optional



iOS device and USB cable




Router with WPS





Network cable

\* For detailed instructions or assistance, please refer to the enclosed CD-ROM manual or visit our support site: [www.marantz.com](http://www.marantz.com)




# 1. Connection

**1** Connect the left and right speakers to the M-CR510



**2** Connect the power cord from the M-CR510 to a power outlet

**3** Insert the batteries into the remote





## 2. Connecting to your home network



Choose from one of the following options

**Wireless**



**iOS device + USB cable**

- 1 Power on
- 2 Select language 
- 3 Make sure your iOS device is already connected to your WiFi Network then connect your iOS device to the front using your USB cable. Note: You must be running iOS version 5 or later 


**No WPS router**

- 1 Power on
- 2 Select language 
- 3 Auto scan  
Please wait as your M-CR510 looks for available networks... 

**WPS router**

- 1 Power on
- 2 Select language 
- 3 Press the WPS button on your router 

**Wired**

- 1 Connect a network cable between your M-CR510 and your router (cable not included) 
- 2 Power on

**4** Press the red Wi-Fi CONNECT Button on the back of your M-CR510

**5** This message will appear on your iOS device. Select "Allow"









Connected!

**4** Select your network name. If your network name is not listed, select "Rescan"

**5** Enter your network password using the number keys on the remote control

Connected!

**4** Within 2 minutes, Press and Hold the red Wi-Fi CONNECT button on the back of your M-CR510 for 3 seconds



**5** Please wait as completing the connection can take a few minutes. The front panel of the M-CR510 will show the status of the connection




Connected!


**3** Select language

**4** Please wait while your M-CR510 connects to your wired network.





Connected!

### Network Control



Select Network Control ON to control M-CR510 from your smartphone, use Apple AirPlay® and maintain constant network access. Power Consumption during standby power will be slightly higher.




Select Network Control OFF to reduce power consumption during standby. You can not turn on your M-CR510 from your smartphone or use Apple AirPlay until your M-CR510 is powered on manually and connects to your network.

### Setup Complete!



### 3. Enjoying your music!

#### Enjoying Internet radio

- 1 Press the “INTERNET RADIO” button on the remote




- 2 Select a station




#### Enjoying music using Apple AirPlay


- 1 Tap the AirPlay Icon from within any app that supports AirPlay



- 2 Select the “Marantz M-CR510” from the AirPlay Device list



Note: Make sure your iOS device is on the same network as the M-CR510



Español / Française / English

## Download the Marantz Remote App

Scan the QR code to download and install the Marantz Remote App using your smartphone and a scanning app or manually search the Apple App store or Google Play store for the “Marantz Remote App”

